

Random Access Memory
GENERAL PURPOSE DISK CONTROL WITH FORTRAN

prepared for
presentation at

SWAP-14 Conference
Chicago, Illinois
April 22-24, 1968

cc-68-16

by

R. E. Schoenborn

Computer Center
Oregon State University
Corvallis, Oreg. 97331

R. E. Schoenborn, Research Associate
Computer Center
Oregon State University
Corvallis, Oregon 97331

Random Access Memory
GENERAL PURPOSE DISK CONTROL WITH FORTRAN*

The original purpose of this program was to exchange computer time for more memory storage space. The requirement of the specific program for which this subroutine was developed was the need for quick access to variable length records which were to be modified on-line and returned to storage. To speed up this process no attempt was made in this application to keep track of space no longer used or needed and while the data was of variable length, the indices were of fixed length and location. The reasoning behind this procedure was that any system that can afford the costs of on-line modification (such as with data display devices) must also afford the costs of back-up dumps to protect itself from machine failure.

The characteristics of this subroutine are that it allows the user to a] modify the program easily to match any random access memory, b] provide the user with the facility to write in either fixed length or variable length mode, with or without the user being aware of the present state of the files in the random access memory and finally c] to provide the user with the facility for detecting errors.

In any general purpose program there is the problem of how much control such a program should have and how much latitude is allowed the user. This latitude may prove a burden to some users and a limit to others. Also, one must weigh the overhead added by a general purpose program against the benefits provided to the user.

Perhaps an example of how this subroutine is used will be most useful in explaining how it works. A listing of the HISTDATA program is attached. The purpose of this program is to build a file of data on the RAM device in such a way that it is readily callable on the data displays. This calls for opening the previously initiated RAM device and testing it to determine that it was properly closed when last used. Next, data is collected in fixed blocks, stored, and the locations noted in an index. Finally, the last odd sized block is stored and the index and count blocks returned to the RAM. The RAM is then closed.

*The work described in this article was completed under a grant from the National Science Foundation.

In the opening, GENRAMOI gets a small block of data (presently set at 50 words as developed and stored during initialization) which contains, a] a flag word, b] number of words available on the RAM device (amount allocated), c] number of words used, d] next available block and word locations and e] additional space that the systems designer may use. The flag word is checked to determine if the RAM was properly initialized or closed the last time it was used.

The flag is returned in the operations parameter as to the status of the RAM. The user then may proceed to do the required work or take corrective action if so indicated.

In another example, the user may elect to write in an area of his own choosing and if he does, GENRAMOI will test to see that such a write will not exceed the available space and that the "Next available location address" which it maintains is properly updated, if necessary.

The six operations available to the user are (in the order of their use):

- 4 - Set up new RAM
- 2 - Open RAM previously set up or used
- 1 - Write on RAM
- 5 - Read from RAM
- 3 - Close RAM (also does Emergency Close)
- 6 - Write on RAM at location indicated by user

The Call for each operations parameter and the possible flag responses and operations of the subroutine are shown in the table which is attached to the documentation.

Again, this program was the result of a situation which required a system to receive, store, and retrieve data from four data display units simultaneously. Before it was written the disk used required a space allocation of 850 of the 1000 available tracks. After this program was installed the block and word address, which are returned by the subroutine and stored on the disk in fixed format index with the #6 function, indicated that only 60 fully packed tracks of data were required.

The listing of GENRAMOI which is presented here is for users without BDP units. Oregon State University's CDC 3300 happens to have one and we make use of it with a call to a small COMPASS routine for moving, blanking and zeroing blocks of memory in core. Listings for the BDP user, with or without the COMPASS routines, are also available.

Briefly then, GENRAMOI attempts to be readily adaptable to any RAM device, or system using such devices. It attempts to provide the user with as much or as little control as they wish to exercise with as little overhead as is possible in any abstracted language, such as FORTRAN.

1.0 Identification:

- 1.1 GENRAMOI
- 1.2 R. E. Schoenborn
- 1.3 Computer Center, Oregon State University
- 1.4 20 June 1967

2.0 Purpose:

- 2.1 The purpose of this program is to provide a general subroutine in FORTRAN, to be called by FORTRAN, to allow I/O with any RAM unit of variable length records without gaps in the RAM. To provide a useful subroutine to use, as efficiently as possible, all available space provided by a RAM device, whether for temporary or permanent storage. Program length: approx. 1,000 words plus 2 blocks.

3.0 Usage:

- 3.1 Calling Sequence: Call GENRAMOI (Request and response codes, NR of words, list, track #, word #)
- 3.2 Inputs and formats are: (See example) Function Code-- 1 to 6, NR of words to be handled, BUFFER to read/write from, track and word related to flag.
- 3.3 Outputs and formats are: (See attached examples) Flag returned in first parameter location.
- 3.4 Process used on Inputs to get Outputs:
 - 3.4.1 Output: Data moved from table to physical record size area, packed consecutively with previous data and written to RAM.
 - 3.4.2 Input: Physical size records read from RAM and requested data unpacked from consecutive locations and moved to table of requesting program.
- 3.5 List of error conditions, messages and operator actions: Response codes are returned to the calling program as noted on explanation example sheet.
- 3.6 List of time constraints and order of operation with respect to other programs: User need not be concerned with any RAM I/O operation since this program lists for conclusion of operations before RAM is used and does not return to user until all operations are concluded.
- 3.7 List of Equipment (Computer, Peripherals, off-line) to be used: Random Access Memory device equipped in EQUIP card and parameters described to program via COMMON/ DATA/ statements.
- 3.8 List of systems, programs & subroutines available for use: GENMOVE (See attached listing).

	NFUNT	NBLOKSIZ	NAMBUFR	NRTRK	NWDPTR	CONDITION
Call GENRAMOI(4,,,,)						
Req	4	--	--	--	--	Set up new RAM
Resp	1	--	--	--	--	O.K.
Resp	4	--	--	--	--	No go--System not able to find RAM track
Req	*	--	--	--	--	Illegal Request
Resp	3	--	--	--	--	No action
Call GENRAMOI(2,,,,)						
Req	2	--	--	--	--	Initialize RAM previously set up or used
Resp	1	--	--	--	--	O.K.
Resp	5	--	--	--	--	RAM not originally set up or closed after last usage. Next available location provided for Req'd. write out may write on previous records. Write at your own risk. Read Req. will not go beyond Next Available Location. (See Call Option 3)
Call GENRAMOI(1,1000,NLIST,NTRACK,NRWRD)						
Req	1	1000	NLIST	--	--	Write 1000 Word Buffer from NLIST
Resp	1	1000	NLIST	75	342	O.K. 1000 Words are on RAM Starting at Track 75 Word 342
Resp	2	1000	NLIST	--	--	Blocksize would Exceed available RAM size or limit NO Action.

Figure 1

	NFUNT	NBLOKSIZ	NAMBUFR	NRTRK	NWDPTR	CONDITION
	Call GENRAMOI(5,660,MYBUFFER,819,737)					
Req	5	660	MYBUFFER	819	737	Read and pack 660 word into MYBUFFER starting from Track 819 Word 737
Resp	1	660	MYBUFFER	819	737	O.K.
Resp	2	660	MYBUFFER	819	737	Read Req. goes beyond next available location No Action
Resp	4	660	MYBUFFER	819	737	No Action, System not able to locate RAM Track
	Call GENRAMOI(3,,,**,***)					
Req	3	--	--	--	--	Close Shop--Return next available locations to RAM.
	Call GENRAMOI(3,*,,**,***)					
Req	3	*Computed or estimated no. of words used	--	**Next available track, to be inserted	***Next available word, to be inserted	When RAM was not closed after a previous usage (program or machine failure) this emergency closing option may be requested Might be called after getting a Resp 5 code to an initialize Call (#2).
Resp	1	--	--	--	--	O.K.--Goodbye
	Call GENRAMOI(6,4745,INDEX,2,1)					
Req	6	4745	INDEX	2	1	Write 4745 word buffer from INDEX to RAM starting at Track 2 Word 1.
Resp	1	4745	INDEX	2	1	O.K. (See Notes on NFUNT = 1)
Resp	2	4745	INDEX	2	1	No go. (See Notes on NFUNT = 2)

Figure 2

```

SUBROUTINE GENRAM01 (NFUNT,NBLOKSIZ,NAMBUFR,NRTRK,NWDPTR)
      22 - G E N      WITHOUT B D P UNIT
      EQUIP RANDOM ACCESS MEMORY(RAM) TO 7 FOR THIS ROUTINE
      THIS ROUTINE IS A FILE ASSIGNMENT PROGRAM FOR USE WITH
      A RANDOM ACCESS MEMORY DEVICE. CHANGES TO THE PROGRAM ARE
      ARE NECESSARY ON CARDS MARKED ***** TO DEFINE MAX NR WORDS
      ON RAM DEVICE AND MAX NR OF WORDS ON A TRACK/SECTOR
      FILES ARE PACKED IN CONSECUTIVE LOCATIONS W/O LOSS OF SPACE
      MAXNR = MAX NR OF MACH WDS ON RAM OR SIZE OF ASSIGNED AREA
      MTRKSIZ = MAX NR WORDS ON A TRACK OR SECTOR
      INPTR = 0 POINTERS NOT READ IN YET
      NSTART = TRACK TO START WORKING FROM
      1ST 50 WORDS ARE RESERVED FOR THIS PROGRAM. 1ST AVAIL WD = 51.
      REQUEST IS - - -
      NFUNT = 1 TO ADD NEW BLOCK OF DATA TO R A M
      NFUNT = 2 OPEN      R A M AND GET PREVIOUS FILE DATA
      NFUNT = 3 CLOSE SHOP AND SAVE INFO ON RAM, IF NRTRK =0 OR BLK
      NFUNT = 4 START UP A NEW DISC PACK OR RAM
      NFUNT = 5 READ 1 NBLOKSIZ RECORD FROM NRTRK AT NWDPTR INTO
      NAMBUFR.
      NFUNT = 6 USER CONTROLLED WRITE.. NEXTAVAIL TRACK AND WORD
      MODIFIED ONLY IF NECESSARY
      NBLOKSIZ = NR OF WORDS IN/OUT TO/FROM BUFFER = NAMBUFR
      NRTRK AND NWDPTR = TRACK AND WORD STARTING LOCATION OF RECORD
      USER CAN PUT IT IN AN INDEX IF NECESSARY AFTER WRITE AND
      SUPPLY THEM FOR NFUNT =5 CALL
      RESPONSE IS - - -
      NFUNT = 1 IF O K      =2 IF RAM AREA EXCEEDED =3 IF REQ NOT
      COMPLETE OR CORRECT
      NFUNT =4 TRACK NOT FOUND      =5 NXAVAIL POINTER NOT RETURNED
      TO DISC LAST TIME.
      *****
      DIMENSION NAMBUFR(2),NTRBUF(1024,2),INBUF(2)
      GO TO (900,40,10,600,942,300,400,900) NFUNT+1
      10 MAXNR=1000000 $ MTRKSIZ=1024 $ NSTART=1 $ INPTR=0
      GOTO (11,960) LOCATEF (7,NSTART)
      READ IN NEXT AVAILA LOCTIONS AND INITIALIZE
      11 BUFFER IN (7,1) (NTRBUF(1,1),NTRBUF (MTRKSIZ,1))
      1100 GOTO (1100,1110) UNITSTF (7)
      1110 IF (NTRBUF(5,1) .EQ. 4HOKOK) 1120,1130
      1120 NXAVTRK= NTRBUF(1,1) $NXAVWD=NTRBUF(2,1) $INBUF(1)=0
      JY = 1$ NRLEFT=MTRKSIZ $ MAXNR = NTRBUF (3,1)
      NRUSED = NTRBUF (4,1)
      GOTO (1140,960) LOCATEF (7,NSTART)
      RAM IS NOT SET UP RIGHT
      1130 NFUNT=5 $ RETURN
      1140 NTRBUF (5,1) =0
      BUFFER OUT (7,1)(NTRBUF(1,1),NTRBUF(MTRKSIZ , 1))
      SET FLAG O. K.
      13 NFUNT=1 $ RETURN
      SET UP TO MOVE BUFFER AND WRITE TRACKS
      40 NRNEED = NBLOKSIZ
      KPTR =1
      ITEMTRK= NRTRK=NXAVTRK
      ITEMWD = NWDPTR = NXAVWD
      IF ((NRUSED+NRNEED) .GT. MAXNR) 950, 50
      TEST IF NEXT AVAILABLE TRACK IN BUFFERS

```

50 IF (INBUF(1) .EQ. NXAVTRK) 90,52	KIT00600
52 IF (INBUF(2) .EQ. NXAVTRK) 92,70	KIT00610
C * * * READ IN PARTLY FILLED TRACK	KIT00620
70 IF (NXAVWD .EQ. 1) 120,72	KIT00630
72 GOTO (74,76) JY	KIT00640
74 JY=2 \$ GOTO 78	KIT00650
76 JY =1	KIT00660
78 GOTO (80,960) LOCATEF (7,NXAVTRK)	KIT0067*
80 BUFFER IN (7,1)(NTRBUF(1,JY),NTRBUF(MTRKSIZ, JY))	KIT0068*
INBUF(JY) = ITEMTRK	KIT00690
88 GOTO (88,120) UNITSTF(7)	KIT0070*
90 JY = 1 \$ GOTO 120	KIT00710
92 JY = 2	KIT00720
120 NRLEFT = MTRKSIZ - ITEMWD +1	KIT00730
125 IF (NRNEED .GT. NRLEFT) 130,160	KIT00740
C * * * MOVE OUT PART OF BUFFER	KIT00750
C*130 CALL GENMOVE (NAMBUFR(KPTR),NTRBUF(ITEMWD,JY),NRLEFT)	KIT0076*
130 IP=KPTR \$ JP=ITEMWD \$ IT=KPTR+NRLEFT-1 \$ GOTO 132	KIT00761
131 IP=IP+1 \$ JP=JP+1	KIT00762
132 NTRBUF(JP,JY)=NAMBUFR(IP) \$ IF (IT-IP) 131,132	KIT00763
133 GOTO (133,134) UNITSTF(7)	KIT0077*
134 GOTO (136,900) LOCATEF (7,ITEMTRK)	KIT0078*
136 BUFFER OUT (7,1)(NTRBUF(1,JY), NTRBUF(MTRKSIZ,JY))	KIT0079*
INBUF(JY) = ITEMTRK	KIT00800
GOTO (140,144) JY	KIT00810
140 JY=2 \$ GOTO 150	KIT00820
144 JY=1	KIT00830
150 ITEMTRK = ITEMTRK + 1	KIT00840
NRNEED = NRNEED - NRLEFT	KIT00850
KPTR = KPTR + NRLEFT	KIT00860
ITEMWD = 1	KIT00870
NRLEFT = MTRKSIZ	KIT00880
GOTO 125	KIT00890
C*160 CALL GENMOVE (NAMBUFR(KPTR),NTRBUF(ITEMWD,JY),NRNEED)	KIT0090*
160 IP=KPTR \$ JP=ITEMWD \$ IT=KPTR+NRNEED-1 \$ GOTO 162	KIT00901
161 IP=IP+1 \$ JP=JP+1	KIT00902
162 NTRBUF(JP,JY)=NAMBUFR(IP) \$ IF (IT-IP) 161,163	KIT00903
163 GOTO (163,164) UNITSTF(7)	KIT0091*
164 GOTO (166,900) LOCATEF(7,ITEMTRK)	KIT0092*
166 BUFFEROUT (7,1) (NTRBUF(1,JY),NTRBUF(MTRKSIZ,JY))	KIT0093*
INBUF(JY) = ITEMTRK	KIT00940
C * * * TEST IF TRACK COUNT SHOULD BE CHANGED	KIT00950
NXAVWD = NXAVWD + NBLOKSIZ	KIT00960
170 IF (NXAVWD .LE. MTRKSIZ) 175,172	KIT00970
172 NXAVTRK=NXAVTRK+1	KIT00980
NXAVWD=NXAVWD-MTRKSIZ \$ GOTO 170	KIT00990
175 NRUSED=NRUSED+NBLOKSIZ	KIT01000
177 GOTO (177,13) UNITSTF(7)	KIT0101*
C * * * READ IN REQUEST =5	KIT01020
300 NRNEED=NBLOKSIZ	KIT01030
ITEMWD=NWDPTR+NBLOKSIZ-1	KIT01040
ITEMTRK=NRTRK \$JY=1	KIT01050
KPTR=1	KIT01060
302 IF (ITEMWD .LE. MTRKSIZ) 308,304	KIT01070
304 ITEMWD=ITEMWD-MTRKSIZ	KIT01080
ITEMTRK=ITEMTRK+1 \$GO TO 302	KIT01090
308 IF (ITEMTRK-NXAVTRK) 316,312,950	KIT01100
312 IF (ITEMWD.LT.NXAVWD) 316,950	KIT01110
316 ITEMTRK=NRTRK \$ ITEMWD=NWDPTR	KIT01120
IF (NRTRK .EQ. INBUF(1)) 321,320	KIT01130

320 IF (NRTRK.EQ.INBUF(2)) 322,380	KIT01140
321 NRBUF=1 \$ JY = 2 \$ GOTO 324	KIT01150
322 NRBUF=2 \$ JY = 1	KIT01160
324 NRLEFT=MTRKSIZ+1-ITEMWD	KIT01170
328 IF (NRNEED.GT.NRLEFT) 338,333	KIT01180
C*333 CALL GENMOVE (NTRBUF(ITEMWD,NRBUF),NAMBUFR(KPTR),NRNEED)	KIT0119*
333 IP=KPTR \$ JP=ITEMWD \$ IT=KPTR+NRNEED-1 \$ GOTO 335	KIT01191
334 IP=IP+1 \$ JP=JP+1	KIT01192
335 NAMBUFR(IP)=NTRBUF(JP,NRBUF) \$ IF (IT-IP) 334,13	KIT01193
C* GO TO 13	KIT01200
338 ITEMTRK=ITEMTRK+1	KIT01210
GOTO (340,960) LOCATEF(7,ITEMTRK)	KIT0122*
340 BUFFER IN (7,1)(NTRBUF(1,JY),NTRBUF(MTRKSIZ,JY))	KIT0123*
C* CALL GENMOVE (NTRBUF(ITEMWD,NRBUF),NAMBUFR(KPTR),NRLEFT)	KIT0124*
IP=KPTR \$ JP=ITEMWD \$ IT=KPTR+NRLEFT-1 \$ GOTO 344	KIT01241
342 IP=IP+1 \$ JP=JP+1	KIT01242
344 NAMBUFR(IP)=NTRBUF(JP,NRBUF) \$ IF (IT-IP) 342,346	KIT01243
346 KPTR=KPTR+NRLEFT	KIT01250
NRNEED=NRNEED-NRLEFT	KIT01260
INBUF(JY)=ITEMTRK	KIT01270
NRLEFT=MTRKSIZ	KIT01280
GO TO (350,352)JY	KIT01290
350 JY=2 \$NRBUF=1 \$GO TO 356	KIT01300
352 JY=1 \$NRBUF=2	KIT01310
356 ITEMWD=1	KIT01320
360 GO TO (360,328) UNITSTF(7)	KIT0133*
380 GO TO (380,384) UNITSTF(7)	KIT0134*
384 GOTO (388,960) LOCATEF(7,ITEMTRK)	KIT0135*
388 BUFFER IN (7,1)(NTRBUF(1,1),NTRBUF(MTRKSIZ,1))	KIT0136*
INBUF(1)=ITEMTRK	KIT01370
390 GO TO (390,321) UNITSTF(7)	KIT0138*
C * * * USER CONTROLLED WRITE (REQ = 6). IF WRITE GOES BEYOND	KIT01390
C * * * NEXTAVAIL TRACK AND WORD THESE WILL BE RESET. OTHERWISE	KIT01400
C * * * NOTHING IS AFFECTED. RETURN FLAGS SAME AS REGULAR WRITE.	KIT01410
400 LPTR=1 \$ NNRTK=NRTRK	KIT01420
NRA=NRTRK*MTRKSIZ+NWDPTR+NBLOKSIZ	KIT01430
NRB=NBLOKSIZ \$ NRC=NWDPTR	KIT01440
IF (NRA .GT. MAXNR) 950,402	KIT01450
C * * * TEST FOR FULL TRACK OUTPUT	KIT01460
402 IF (NRC .EQ. 1) 404,420	KIT01470
404 IF (NRB .LT. MTRKSIZ) 420,406	KIT01480
C * * * SET UP AND MOVE FULL TRACK FROM USERS TABLE	KIT01490
406 GOTO (410,960) LOCATEF(7,NNRTK)	KIT0150*
410 NRMOV=LPTR+MTRKSIZ-1	KIT01510
BUFFEROUT (7,1) (NAMBUFR(LPTR),NAMBUFR(NRMOV))	KIT0152*
LPTR=LPTR+MTRKSIZ \$ NNRTK=NNRTK+1	KIT01530
NRB=NRB-MTRKSIZ	KIT01540
412 GOTO (412,453) UNITSTF(7)	KIT0155*
C * * * SET UP TO MOVE PARTIAL TRACK...TEST IF TRACK IN CORE	KIT01560
420 IF (INBUF(1) .EQ. NNRTK) 440,422	KIT01570
422 IF (INBUF(2) .EQ. NNRTK) 442,425	KIT01580
425 GOTO (427,428) JY	KIT01590
427 JY=2 \$ GOTO 430	KIT01600
428 JY=1	KIT01610
430 GOTO (433,960) LOCATEF(7,NNRTK)	KIT0162*
433 BUFFERIN (7,1) (NTRBUF(1,JY),NTRBUF(MTRKSIZ,JY))	KIT0163*
INBUF(JY)=NNRTK	KIT01640
435 GOTO (435,445) UNITSTF(7)	KIT0165*

440 JY=1 \$ GOTO 445	KIT01660
442 JY=2	KIT01670
445 NRMOV=MTRKSIZ-NRC+1	KIT01680
IF (NRMOV .GT. NRB) 447,450	KIT01690
447 NRMOV=NRB	KIT01700
C*450 CALL GENMOVE (NAMBUFR(LPTR),NTRBUF(NRC,JY),NRMOV)	KIT0171*
450 IP=LPTR \$ JP=NRC \$ IT=LPTR+NRMOV-1 \$ GOTO 452	KIT01711
451 IP=IP+1 \$ JP=JP+1	KIT01712
452 NTRBUF(JP,JY)=NAMBUFR(IP) \$ IF (IT-IP) 451,453	KIT01713
453 GOTO (454,960) LOCATEF(7,NNRTRK)	KIT0172*
454 BUFFEROUT (7,1) (NTRBUF(1,JY),NTRBUF(MTRKSIZ,JY))	KIT0173*
NRC=1 \$ NRB=NRB-NRMOV	KIT01740
NNRTRK=NNRTRK+1 \$ LPTR=LPTR+NRMOV	KIT01750
455 GOTO (455,456) UNITSTF(7)	KIT0176*
456 IF (NRB) 402,460	KIT01770
C * * * TEST IF NEXTAVAIL INFO NEEDS UPDATING	KIT01780
460 NTK=NRTRK \$ NWD=NWDPTR+NBLOKSIZ-1	KIT01790
462 IF (NWD .LT. MTRKSIZ) 470,465	KIT01800
465 NWD=NWD-MTRKSIZ \$ NTK=NTK+1 \$ GOTO 462	KIT01810
470 IF (NXAVTRK-NTK) 472,476,13	KIT01820
472 NXAVTRK=NTK \$ GOTO 480	KIT01830
476 IF (NWD .LT. NXAVWD) 13,480	KIT01840
480 NXAVWD=NWD+1 \$ GOTO 13	KIT01850
C * * * ALL DONE - CLEAN UP ... RETURN POINTERS TO DISC	KIT01860
600 GOTO (600,602) UNITSTF (7)	KIT0189*
602 GOTO (604, 960) LOCATEF (7,NSTART)	KIT0190*
604 BUFFER IN (7,1)(NTRBUF(1,1), NTRBUF (MTRKSIZ,1))	KIT0191*
606 GOTO (606,608) UNITSTF(7)	KIT0192*
608 IF (NRTRK .EQ. 4H) 617, 610	KIT01921
610 IF (NRTRK .EQ. 0) 617, 612	KIT01922
C REBUILD DISK OPEN AFTER BLOW UPR OR SUMTHIN	KIT01923
612 NTRBUF (1,1) = NRTRK \$NTRBUF(2,1)=NWDPTR\$NTRBUF(4,1)=NBLOKSIZ	KIT01924
GOTO 620	KIT01925
617 NTRBUF(1,1) = NXAVTRK \$ NTRBUF(2,1)=NXAVWD	KIT01930
NTRBUF(4,1) = NRUSED	KIT01940
620 NTRBUF (3,1) = MAXNR	KIT01950
620 NTRBUF(5,1)= 4HOKOK	KIT01960
GOTO (930,960) LOCATEF(7,NSTART)	KIT0197*
930 BUFFEROUT (7,1) (NTRBUF(1,1),NTRBUF(MTRKSIZ,1))	KIT0198*
940 GOTO (940,13) UNITSTF(7)	KIT0199*
942 NTRBUF(1,1) = 1 \$ NTRBUF (2,1)=51	KIT02000
NTRBUF(3,1)=1000000 \$ NTRBUF(4,1)=0 \$ MTRKSIZ=1024	KIT0****
NSTART=1	KIT0***
GOTO 629	KIT02020
C * * * INPUT REQUEST ERRONEOUS. RETURN BAD FLAG.	KIT02022
900 NFUNT= 3 \$ RETURN	KIT02025
C * * * ALLOCATED RAM AREA TO SMALL FOR NEXT RECORD,SET FLAG	KIT02030
950 NFUNT= 2 \$NRTRK=NWDPTR=0 \$ RETURN	KIT02040
C * * * CANNOT FIND TRACK, SET FLAG	KIT02050
960 NFUNT=4 \$ RETURN	KIT02060
END	KIT02070

```

IDENT      MOVE
ENTRY      GENFILL,GENMOVE
*          1/26/68
*****
*** HI SPEED XERO FILL,BLANK FILL OR BUFFER MOVE ***
*** BY USE OF B.D.P. UNIT. ANY PLACE A DO LOOP IS USED FOR THESE ***
*** PURPOSES GREATER EFFICIENCY CAN BE EFFECTED BY USE OF THIS ROUTINE. ***
*** USE IN FORTRAN PROG AS FOLLOWS... ***
*** CALLGENFILL(8 OR 16, BUFF, NRWORDS) ***
***      8= BLANK FILL      16= ZERO FILL ***
*** CALL GENMOVE(FROMBUFF, TOBUFF, NRWORDS) ***
*** BUFFER ADDRESS MAYBE SUBSCRIPTED. NRWORDS .LE. 1023 ***
*** EXAMPLE BLANK A 4000 WORD BUFFER ***
*** DIMENSION MATRIX (4000) ***
*** DO 6 I=1,4000,1000 ***
*** CALL GENFILL (1,MATRIX(I), 1000) ***
*** 6 CONTINUE ***
*****
GENMOVE    UJP      **
           STI      TEMP,3          SAVE INDEX
           LDI      GENMOVE,3
           LDA      0,3            GET FROM ADDRESS
           SHA      2              CONVERT TO CHAR. ADD.
           ANA,S    77774B         MASK IT AND
           SCHA     MOVE          STORE
           ENA,S    0
           END,S    70000B
SAME       SACH     MOVE+4
           LDA,I    2,3            GET NR OF WORDS TO MOVE
           SHA      2
           AQA
           STA      MOVE+2
           INI      3,3            SET INDEX TO RETURN LOCATION
           STI      GENFILL,3
           LDA      -2,3           GET BUFFER ADD/TO ADD.
           SHA      2              CONVERT TO CHAR. ADD.
           ANA,S    77774B         MASK IT
           SCHA     MOVE+1
MOVE       MVE      MOVE+4,0,0,0,0 MOVE OR BLANK/ZERO FILL
TEMP      ENI      **,3
GENFILL    UJP      **
           STI      TEMP,3          SAVE INDEX
           LDI      GENFILL,3
           LDA,I    0,3            GET OPTION. 8=BLANK 16= ZERO
           ENQ,S    0
           UJP      SAME
           END

```

IDENT MOVE
ENTRY GENMOVE,GENFILL

```

***  HI SPEED XERO FILL,BLANK FILL OR BUFFER MOVE          ***
***                USE IN FORTRAN PROG AS FOLLOWS...      ***
***  CALLGENFILL(8 OR 16, BUFF, NRWORDS)                   ***
***                8= BLANK FILL      16= ZERO FILL        ***
***  CALL GENMOVE(FROMBUFF, TOBUFF, NRWORDS)                ***
***  BUFFER ADDRESS MAYBE SUBSCRIPTED.      NRWORDS .LE. 1023 ***
***  EXAMPLE                BLANK A    4000 WORD BUFFER    ***
***  DIMENSION MATRIX (4000)                                ***
***  DO 6 I=1,4000,1000                                     ***
***  CALL GENFILL (1,MATRIX(I), 1000)                       ***
***  6  CONTINUE                                           ***

```

GENMOVE	UJP	**	
	STI	TEM,1	SAVE INDEX
	LDI	GENMOVE,1	LOAD ADDRESS OF PARAMETER LIST
	STI	GENFILL,1	STORE RETURN ADDRESS
	LDAQ	0,1	GET ADDRESS OF FROM AND TO BUFS
	SWA	LOAD	STORE LOAD ADDRESS
	SHAQ	24	
	SWA	STORE	STORE STORE ADDRESS
	LDA,I	2,1	LOAD NO OF WORDS TO MOVE
	TAI	1	TRANSFER WORD COUNT TO INDEX
	INI	-1,1	
LOAD	LDA	**,1	LOAD WORD
STORE	STA	**,1	STORE WORD
	IJD	*-2,1	
OUT	ENA	3	
	RAD	GENFILL	INCREASE RETURN ADDRESS BY THREE
TEM	ENI	**,1	
GENFILL	UJP	**	
	STI	TEM,1	SAVE INDEX
	LDI	GENFILL,1	LOAD ADDRESS OF PARAMETER LIST
	LDA	1,1	LOAD ADDRESS OF BUFFER AND
	SWA	STOR	STORE
	LDQ,I	0,1	LOAD FLAG DATA
	LDA,I	2,1	LOAD COUNT
	TAI	1	TRANSFER COUNT TO INDEX
	INI	-1,1	DECREASE BY ONE
	ENA	0	LOAD A WITH ZERO
	QSE	16	IF FLAG IS 16 STORE ZERO
	LDA	=H	OTHERWISE STORE BLANKS
STOR	STA	**,1	STORE BLANKS OR ZEROS
	IJD	*-1,1	
	UJP	OUT	
	END		

```

C * * * * * DEMONSTRATION OF PROGRAM USING G E N R A M O I * * * *
PROGRAM HISTDATA
C * * * * * 27 RESV * * * * *
C * * * * * THIS PROGRAM IS TO ENTER HISTORY DATA TO THE FILE TO BE
C * * * * * CALLED FROM DATA DISPLAY UNIT
C * * * * *
INTEGER GENRAMOI,DISKFIX
COMMON/DATA/ITOTAL(10),IBILPTCT,IBSORTCT,ITR(26),IWD(26),HIGH(17)
1IDAUTH(12),IDS(3,24),IDELAY(18),IDOT,IDOTT,ITRPT,IWDPT
DATA (IDOT=4H....),(IDOTT=4H....)
DIMENSION IPAGE(500),INDEX(500),BUF(200)
EQUIVALENCE (DOT,IDOT),(TRWDPT,ITRPT),(BUF,INDEX)
1 FORMAT (A8)
2 FORMAT (13A4)
3 FORMAT (R2,12A4)
C * * * * * OPEN PREVIOUSLY INITIALIZED RAM AND TEST FOR POSSIBLE ERROR
1000 IF (GENRAMOI (2,0,0,0,0)-5) 1020,1010
C * * * * * RAM WAS NOT CLOSED LAST TIME. (POSSIBLY DUE TO COMPUTER
C * * * * * FAILURE ) RESTART.
1010 M=DISKFIX(INDEX) $ GOTO 1000
C * * * * * READ IN BLOCK
1020 M=GENRAMOI (5,200,ITOTAL,1,51)
IP=1 $ IPW=101 $ IPC=401
10 READ (20,1) BUF(IP) $ IF (BUF(IP)) 15,70
15 IPTOP=IFLAG=1 $ INDEX(IPC)=0
20 IPTOP=IPTOP+11 $ READ (20,2) (IPAGE(I),I=IPTOP,ITOP),ITEM
IF (IPAGE(IPTOP)-4H****) 25,50
25 IPTOP=ITOP+1 $ ITOP=IPTOP+12 $ READ (20,3) (IPAGE(J),J=IPTOP,ITOP)
IF (IPAGE(IPTOP)-4H00**) 30,60
30 IPAGE(IPTOP)=AND(ITEM,77770000B)+IPAGE(IPTOP)
IPTOP=ITOP+1 $ IF (ITOP-500) 20,80
50 IF (IPTOP-1) 52,58
52 IPTOP=IPTOP-1
54 INDEX(IPC)=INDEX(IPC)+IPTOP
C * * * * * WRITE LAST NEW PAGE TO RAM...GET BLOCK(TRACK) AND WORD
C * * * * * ADDRESS IN ITRPT AND IWDPT
M=GENRAMOI (1,IPTOP,IPAGE,ITRPT,IWDPT)
IF (IFLAG) 57,58
57 BUF(IPW)=TRWDPT
58 IP=IP+1 $ IPW=IPW+1 $ IPC=IPC+1 $ GOTO 10
60 IPAGE(IPTOP)=ITEM $ GOTO 54
70 ITOTAL(7)=IP-1
DO 100 I=IP,100
BUF (I)=DOT $ BUF (I+100)=0. $ INDEX(I+400)=0
100 CONTINUE
C * * * * * FORCED WRITE OF FIXED SIZE INDEX
M=GENRAMOI (6,500,INDEX,ITR(23),IWD(23))
C * * * * * WRITE TOTALS FOR COMMON TABLES USED FOR ALL TYPES OF ACCTS.
C * * * * * CLOSE RAM (RETURN NEXT AVAILABLE ADDRESS ETC TO STORAGE ON RAM)
M=GENRAMOI (6,200,ITOTAL,1,51) $ M=GENRAMOI (3,0,0,0,0) $CALL EXIT
C * * * * * WRITE 1 FULL BUFFER (FIXED SIZE) AS NEW PAGE ...
80 M=GENRAMOI (1,500,IPAGE,ITRPT,IWDPT)
INDEX(IPC)=INDEX(IPC)+500 $ IPTOP=1 $ IF (IFLAG) 85,20
85 BUF(IPW)=TRWDPT $ IFLAG=0 $ GOTO 20
END

```